

**601/602 Ladies Dress Form
Installation Guide**

Please check the following items in your package. If anything is missing or damaged, please contact your dealer immediately.

6 ITEMS

- | | |
|-----------------------|--------------|
| (1) BASE | 1 pc. |
| (2) SPRING | 1 pc. |
| (3) INNER POLE | 1 pc. |
| (4) OUTER POLE | 1 pc. |
| (5) DRESS FORM | 1 pc. |
| (6) TOPPER | 1 pc. |



(1)



(3)



(4)



(5)



(2)



(6)



Step 1

Place BASE (Item 1) firmly on the ground.



Step 2

Insert SPRING (Item 2) through bottom end of INNER POLE (Item 3)



Step 3

Insert INNER POLE (Item 3) into the BASE (Item 1) all the way to the bottom until foot pedal flip up.



Step 4


Use a screw-driver or any similar tool to tighten by inserting into hole and turning clockwise to tighten the INNER POLE into the BASE.

Tips: Please make sure it is REALLY TIGHT! This is the most important part of the installation.



Step 5

Slide OUTER POLE (Item 4) through INNER POLE (Item 3) while stepping on the pedal. Stepping on the pedal makes the “cut” at the top of INNER POLE align.



Step 6

Put the DRESS FORM
over OUTER POLE.



Step 7

Twist TOPPER on the
DRESS FORM.



Congratulation! Installation Complete!

Tips

- You can easily adjust the height or rotate the dress form by:
 1. Stepping on the pedal
 2. Lifting the dress form / Rotate the dress form
 3. Let go of pedal

(If you do not follow these tips, you might damage the interior structure of the dress form.)